



30571.X - 02972
KNX Wheel-Thermostat

GENERAL CHARACTERISTICS AND FUNCTIONS from page 5

COMMUNICATION OBJECTS AND ETS PARAMETERS from page 7

FAQ from page 28

For all the details about the Well-contact Plus system, refer to the installer manual that can be downloaded from the Software ➔ Product Software ➔ Well-contact Plus section of the website: www.vimar.com.


General characteristics and functions

Electronic dial thermostat for room temperature control (heating and air conditioning), KNX standard home automation system, class I temperature control device (contribution 1%) in ON/OFF mode, class IV (contribution 2%) in PID mode, can be interfaced with actuator with KNX proportional analogue outputs to implement a class V modulating room thermostat (contribution 3%), 1 input for electronic temperature sensor 20432, 19432 or 14432 or wired temperature sensor 02965.1, 1 programmable digital input, white/grey LED backlighting - 2 modules. To be completed with Linea, Eikon, Arké, Plana cover plates. For Idea, can be installed using the dedicated mounting frame 16723.

General characteristics


The thermostat is fitted with a front dial to adjust the setpoint (between 4°C and 40°C) and a central white LED backlit display to show the measured temperature, and show the setpoint only when the dial is being used. The circular ring around the display, with RGB backlighting, displays all the thermostat statuses. The device is fitted with 4 front buttons to be used for setting. The thermostat, physical address, parameters and its operation, etc. are configured via the ETS software.

Front view



A	<ul style="list-style-type: none"> • Short press = degrees Celsius/Fahrenheit selection
B	Configurable functions: <ul style="list-style-type: none"> - send scene (only one scene) - light ON/OFF button - show external temperature from connected temperature sensor - choice season (Heating/Cooling)
C	<i>Display</i> <ul style="list-style-type: none"> • off = thermostat off; on = thermostat on • °C = degrees Celsius; °F = degrees Fahrenheit • H = heating; C = air conditioning
D	<i>Dial</i> <ul style="list-style-type: none"> • Rotation ↻ = set point increase (0.1 °C - 0.2 °F) • Rotation ↻ = set point decrease (0.1 °C - 0.2 °F)
E	Illuminating circular ring
F	<ul style="list-style-type: none"> • Power on and off. At power on or off, the thermostat starts in the last operating mode associated with it
G	<ul style="list-style-type: none"> • Short press = fan coil speed adjustment (0-1-2-3 or Proportional/Automatic)

Circular ring



	All lit amber* = thermostat in heating mode and relay active
	All lit blue** = thermostat in air conditioning mode and relay active
	All flashing red = thermostat locked, alarm state
1	<ul style="list-style-type: none"> • Lit amber* = thermostat in heating mode and relay not active • Lit blue** = thermostat air conditioning mode and relay not active

* Amber with automatic colour; of the selected colour if monochrome.

** Blue with automatic colour; of the selected colour if monochrome.

Default behaviour

Thermostat OFF ➔ Protection mode

Thermostat ON ➔ Comfort mode

Behaviour after bus power on/off

Bus power off: -.

Bus power on: the status will be set based on the setting of the parameters and the corresponding telegrams sent over the Bus.

Behaviour after reset

As for Bus power-on.

N.B. The thermostat saves the comfort and standby setpoints set manually by the user; if you wish to reset them, set the ETS parameter "Reset Setpoint Shift in Economy Mode=YES". When switched to "Economy" mode, the thermostat will reset the STBY and CNF values.

General characteristics and functions


Neutral zone

The "Neutral Zone" is an operating mode of the thermostat (only for 4-pipe systems) in which the device keeps the temperature within a temperature range preset by the Winter Setpoint and Summer Setpoint (basically, there is no longer the usual Summer/Winter mode).

If the measured temperature is below the Winter Setpoint, the thermostat switches on the heating valve and heats the room until the temperature exceeds the set value (e.g. 20°C for Comfort mode or 18°C for Standby mode). If the measured temperature exceeds the Summer Setpoint then the thermostat switches on the cooling valve and keeps it on until the temperature falls below the set Summer Setpoint value.

Within the Neutral Zone the thermostat does not switch on any valves and the temperature can vary freely; this zone is therefore nothing more than the difference between the Summer and Winter Setpoints when the room temperature is between the winter setpoint and the summer one.

To avoid excessive temperature fluctuations, set a limited range ($\leq 2^\circ\text{C}$) as shown in the figure below.



Setpoint displayed in Neutral Zone operation

When the thermostat is working in the neutral zone, the setpoint used for the adjustment is always the **Current Setpoint**, namely the one relating to the last heating/cooling mode that came into operation; the value displayed is instead a new setpoint named **"Neutral Zone Setpoint"**, which is the average value between the current summer and winter setpoints.

Changing the temperature of the **"Neutral Zone Setpoint"** (with the "+" and "-" buttons on the thermostat) will also cause a change to the value of the **"Shift Setpoint"** resulting in a shift of the two current summer/winter setpoint values; the room temperature will therefore not become the one set by the guest but that of the summer/winter setpoint which at that moment is closest to the value of the current temperature in the room. Between the two summer/winter setpoints, there is the neutral zone in which the system is not activated.

Mid Season

This function is available from the supervisor only for systems configured with primary and secondary output; when active, it exchanges the 2 main and secondary outputs (and the related parameters too). It is recommended for making minor adjustments (such as $\pm 2^\circ\text{C}$) during mid season periods where it may be more convenient to operate only the secondary circuit (for instance Split).

Configuration

The KNX 02972 thermostat is configured in Neutral Zone mode if the following object is NOT connected: "Enable A: Summer - Winter - control" or "Enable B: Summer - Winter - control". The thermostat can operate in Neutral Zone IF:

- The system has 4 pipes
- Winter Comfort Setpoint < Summer Comfort Setpoint
- Winter Standby Setpoint < Summer Standby Setpoint
- Winter Economy Setpoint < Summer Economy Setpoint
- Antifreeze < Too Hot

If these conditions are not satisfied, you can still commission the thermostat; if there is an error while starting up, the device will remain in **"Protected"** mode and an error message will be displayed.

Types of errors at the time of configuration

Error No.	Description
E1	Selected 2-pipe system instead of 4-pipe system
E2	Winter Comfort Setpoint \geq Summer Comfort Setpoint
E3	Winter Standby Setpoint \geq Summer Standby Setpoint
E4	Winter Economy Setpoint \geq Summer Economy Setpoint
E5	Antifreeze \geq Too Hot

N.B. Errors E2, E3, E4 and E5 may also be displayed if the thermostat is programmed in "4-pipe system" mode without the neutral zone according to the type of Setpoint shown in the table.

Communication objects and ETS parameters

List of existing communication objects and standard settings

No.	ETS name	Function	Description	Type	Flag 1						Priority
					C	R	W	T	U	I	
1	Internal sensor	Internal probe temperature	To see the temperature read by the thermostat sensor (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	R	-	T	-	-	Low
2	External sensor	External NTC probe temperature	To see the temperature read by the wired NTC probe connected to the thermostat (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	R	-	T	-	-	Low
3	External Temperature 1	KNX probe temperature on bus	To see the temperature read by a KNX sensor connected to the bus (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	-	W	-	U	-	Low
4	External Temperature 2	KNX probe temperature on bus	To see the temperature read by a KNX sensor connected to the bus (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	-	W	-	U	-	Low
5	External Temperature 3	KNX probe temperature on bus	To see the temperature read by a KNX sensor connected to the bus (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	-	W	-	U	-	Low
6	External Temperature 4	KNX probe temperature on bus	To see the temperature read by a KNX sensor connected to the bus (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	-	W	-	U	-	Low
7	External Temperature 5	KNX probe temperature on bus	To see the temperature read by a KNX sensor connected to the bus (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	-	W	-	U	-	Low
8	External Temperature 6	KNX probe temperature on bus	To see the temperature read by a KNX sensor connected to the bus (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	-	W	-	U	-	Low
9	External Temperature 7	KNX probe temperature on bus	To see the temperature read by a KNX sensor connected to the bus (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	-	W	-	U	-	Low
10	External Temperature 8	KNX probe temperature on bus	To see the temperature read by a KNX sensor connected to the bus (to see the temperatures measured by thermostats A/B with Well-Contact Suite software, objects nos. 10/11 should be used)	2 byte	C	-	W	-	U	-	Low
11	Current Temperature	A: Temperature	To see the current temperature associated with thermostat-A (weighted average of the various associated probes): this object is used with Well-Contact Suite software to see the temperature measured by thermostat A	2 byte	C	R	-	T	-	-	Low
12	Current Temperature	B: Temperature	To see the current temperature associated with thermostat-B (weighted average of the various associated probes): this object is used with Well-Contact Suite software to see the temperature measured by thermostat B	2 byte	C	R	-	T	-	-	Low
THERMOSTAT A:											
13	Comfort	A: Mode - control	To select COMFORT operating mode by sending a 1 bit or to set the thermostat to STANDBY by sending a 0 bit	1 bit	C	-	W	-	U	-	Low
14	Energy Saving	A: Mode - control	To select ECONOMY operating mode by sending a 1 bit (a 0 bit is ignored)	1 bit	C	-	W	-	U	-	Low
15	Protected	A: Mode - control	To select OFF-ANTIFREEZE operating mode (or Too Hot in the case of air conditioning) by sending a 1 bit.	1 bit	C	-	W	-	U	-	Low
16	Off	A: Mode - control	To select OFF operating mode by sending a 1 bit (a 0 bit is ignored)	1 bit	C	R	W	-	U	-	Low
17	Thermostat Mode	A: Mode - control	To select operating mode by sending a Byte (1 = Comfort, 2 = StandBy, 3 = Economy, 4 = Protection). If you use supervision with Well Contact Suite this object must be associated with a group.	1 byte	C	-	W	-	U	-	Low
18	Thermostat Mode	A: Mode - status	To read the set operating mode by sending a Byte (1 = Comfort, 2 = StandBy, 3 = Economy, 4 = Protection). If you use supervision with Well Contact Suite this object must be associated with a group.	1 byte	C	R	-	T	-	-	Low

Communication objects and ETS parameters

Continued

No.	ETS name	Function	Description	Type	Flag 1						Priority
					C	R	W	T	U	I	
19	Status	A: Mid season - status	To read the seasonal mode set on the thermostat (0 = MS Not Active, 1 = MS Active)	1 bit	C	R	-	T	-	-	Low
20	Enable	A: Mid season - control	To select the seasonal mode set on the thermostat (0 = MS Not active, 1 = MS Active)	1 bit	C	-	W	-	U	-	Low
21	Status	A: Summer - Winter - status	To read the seasonal mode set on the thermostat (0 = Summer, 1 = Winter)	1 bit	C	R	-	T	-	-	Low
22	Enable	A: Summer - Winter - control	To set the seasonal mode on the thermostat (1 = Winter, 0 = Summer). If it is NOT associated with a group then thermostat A will function in Neutral Zone mode.	1 bit	C	-	W	-	U	-	Low
23	Thermostat Off	A: OFF communication - bus - control	This function is useful in the event of faults on the heating system to disable the valves with a 1 bit.	1 bit	C	-	W	-	U	-	Low
24	Dewpoint	A: Thermostat - control	If a 1 bit is sent to this object, the thermostat turn OFF and stop the air conditioner (this works only in air conditioning mode and serves for example to avoid condensation on the floor) - Note: The thermostat requires a cyclical send to this object, with a time that can be set in the parameter "Dewpoint Supervision Time"	1 bit	C	-	W	-	U	-	Low
25	NOT USED										
26	Current Setpoint	A: Setpoint - status	To read the temperature setpoint set on the thermostat. If you want Well-contact Suite to know the setpoint currently set on the thermostats, this object must be linked to a group	2 byte	C	R	-	T	-	-	Low
27	Setpoint Shift	A: Setpoint - status, control	To read and control a temperature shift with respect to the current setpoint (setpoint set by ETS on the thermostat for the various operating modes CMF, STBY, etc.). The temperature shift permitted is limited to the range set by the parameter: <i>Guest Control Permitted</i> . If parameter <i>Guest Control Permitted is set to Off</i> the "Setpoint Shift" object does not shift the active setpoint.	2 byte	C	R	W	T	-	-	Low
28	Winter Comfort	A: Setpoint - status, control	To read and set the Winter Comfort setpoint.	2 byte	C	R	W	T	U	-	Low
29	Winter Standby	A: Setpoint - status, control	To read and set the Winter Standby setpoint	2 byte	C	R	W	T	U	-	Low
30	Winter Energy Saving	A: Setpoint - status, control	To read and set the Winter Economy setpoint	2 byte	C	R	W	T	U	-	Low
31	Winter Protected	A: Setpoint - status, control	To read and set the Winter Antifreeze setpoint	2 byte	C	R	W	T	U	-	Low
32	Summer Comfort	A: Setpoint - status, control	To read and set the Summer Comfort setpoint	2 byte	C	R	W	T	U	-	Low
33	Summer Standby	A: Setpoint - status, control	To read and set the Summer Standby setpoint	2 byte	C	R	W	T	U	-	Low
34	Summer Energy Saving	A: Setpoint - status, control	To read and set the Summer Economy setpoint	2 byte	C	R	W	T	U	-	Low
35	Summer Protected	A: Setpoint - status, control	To read and set the Summer Too Hot setpoint (power-off of climate control if the window is opened, for instance)	2 byte	C	R	W	T	U	-	Low
36	NOT USED										
37	NOT USED										
38	NOT USED										
Thermostat A: Valves											
39	Cooling Valve	A: Valve	If the "Valve" parameter is set for 4-pipe systems for valve management in Summer: to be used to control the head of a radiating system or the On/Off valve of a fan coil	1 bit	C	R	-	T	-	-	Low
40	Heating Valve	A: Valve	If the "Valve" parameter is set for 4-pipe systems for valve management in Winter: to be used to control the head of a radiating system or the On/Off valve of a fan coil	1 bit	C	R	-	T	-	-	Low
41	Cooling Valve	A: 2-nd stage cooling	If second cooling stage is enabled to be used for the boost function (cooling) for on/off valve control	1 bit	C	R	-	T	-	-	Low
42	Heating Valve	A: 2-nd stage heating	If second heating stage is enabled to be used for the boost function (heating) for proportional valve control	1 byte	C	R	-	T	-	-	Low

Continued

C = Communication; R = Read; W = Write; T = Transmission; U = Enable update

Communication objects and ETS parameters

Continued

No.	ETS name	Function	Description	Type	Flag 1						Priority
					C	R	W	T	U	I	
Thermostat A: Fan											
43	Proportional (0-100%)	A: Fan Inputs	Used to set a proportional speed for the fan coil fan (if the selected fan is proportional with 3 speeds) via a supervisor (e.g., touch screen)	1 byte	C	-	W	-	U	-	Low
44	NOT USED										
45	V1 speed	A: Fan Inputs	Used to force activation of fan coil speed V1 (if the selected fan has 3 speeds)	1 bit	C	-	W	-	U	-	Low
46	V2 speed	A: Fan Inputs	Used to force activation of fan coil speed V2 (if the selected fan has 3 speeds)	1 bit	C	-	W	-	U	-	Low
47	V3 speed	A: Fan Inputs	Used to force activation of fan coil speed V3 (if the selected fan has 3 speeds)	1 bit	C	-	W	-	U	-	Low
48	Automatic	A: Fan Inputs	Used to force activation of fan coil speed AUTO (if the selected fan has 3 speeds)	1 bit	C	-	W	-	U	-	Low
49	NOT USED										
50	Off	A: Fan Outputs	Used to read the deactivation status of all 3 speeds (if the selected fan has 3 speeds). The thermostat sends a 1 bit when the fan is off (fan coil speed 0).	1 bit	C	R	-	T	-	-	Low
51	V1 speed	A: Fan Outputs	This is the object to pair with the relay of speed 1 of the fan coil (to read the status of speed V1 of the fan coil, this object can be polled by the bus)	1 bit	C	R	-	T	-	-	Low
52	V2 speed	A: Fan Outputs	This is the object to pair with the relay of speed 2 of the fan coil (to read the status of speed V2 of the fan coil, this object can be polled by the bus)	1 bit	C	R	-	T	-	-	Low
53	V3 speed	A: Fan Outputs	This is the object to pair with the relay of speed 3 of the fan coil (to read the status of speed V3 of the fan coil, this object can be polled by the bus)	1 bit	C	R	-	T	-	-	Low
54	V1 speed	A: Fan Disable	To disable speed V1 (if the selected fan has 3 speeds)	1 bit	C	R	W	T	U	-	Low
55	V2 speed	A: Fan Disable	To disable speed V2 (if the selected fan has 3 speeds)	1 bit	C	R	W	T	U	-	Low
56	V3 speed	A: Fan Disable	To disable speed V3 (if the selected fan has 3 speeds)	1 bit	C	R	W	T	U	-	Low
Thermostat A: Window											
57	Window Sensor	A: Window	Object to be paired with the input to which a window-contact is connected so that the thermostat switches to OFF-PROTECTED when the window is opened, depending on whether the mode is Air Conditioning or Heating	1 bit	C	-	W	-	U	-	Low
Thermostat A: Scenario											
58	Scenario	A: Scenario	To activate a scenario with a 1 Byte message	1 byte	C	-	W	-	U	-	Low
Thermostat A: Auto/Man											
59	Temperature: Automatic/Manual	A: Manual operation	To see whether the guest has altered the thermostat temperature setpoint with respect to the default setting	1 bit	C	R	-	T	-	-	Low
60	Fan coil: Automatic/Manual	A: Manual operation	To see whether the guest has altered the fan coil speed with respect to the default setting	1 bit	C	R	-	T	-	-	Low
61	Temperature: Disable Local operation	A: Manual operation	Activating this object prevents the guest from altering the setpoint temperature by means of the thermostat buttons with respect to the value set by the bus	1 bit	C	-	W	-	U	-	Low
62	Fan coil: Disable Local Operation	A: Manual operation	Activating this object prevents the guest from altering the fan coil speed by means of the thermostat buttons with respect to the value set by the bus	1 bit	C	-	W	-	U	-	Low

Continued

C = Communication; R = Read; W = Write; T = Transmission; U = Enable update

Communication objects and ETS parameters

Continued

No.	ETS name	Function	Description	Type	Flag 1						Priority
					C	R	W	T	U	I	
Thermostat A: Floor Probe Alarm											
63	Temperature Floor	A: Alarm	If the temperature limitation is active an alarm is sent when the temperature exceeds the set threshold	1 bit	C	R	-	T	-	-	Low
THERMOSTAT B:											
64	Comfort	B: Mode - control	To select COMFORT operating mode by sending a 1 bit or to set the thermostat to STANDBY by sending a 0 bit	1 bit	C	-	W	-	U	-	Low
65	Energy Saving	B: Mode - control	To select ECONOMY operating mode by sending a 1 bit (a 0 bit is ignored)	1 bit	C	-	W	-	U	-	Low
66	Protected	B: Mode - control	To select ANTIFREEZE operating mode (or Too Hot in the case of air conditioning) by sending a 1 bit.	1 bit	C	-	W	-	U	-	Low
67	Off	B: Mode - control	To select OFF operating mode by sending a 1 bit (a 0 bit is ignored)	1 bit	C	R	W	-	U	-	Low
68	Thermostat Mode	B: Mode - control	To select operating mode by sending a Byte (1 = Comfort, 2 = StandBy, 3 = Economy, 4 = Protection). If you use supervision with Well Contact Suite this object must be associated with a group.	1 byte	C	-	W	-	U	-	Low
69	Thermostat Mode	B: Mode - status	To read the set operating mode by sending a Byte (1 = Comfort, 2 = StandBy, 3 = Economy, 4 = Protection). If you use supervision with Well Contact Suite this object must be associated with a group.	1 byte	C	R	-	T	-	-	Low
70	Status	B: Mid season - status	To read the seasonal mode set on the thermostat (0 = MS Not Active, 1 = MS Active)								
71	Enable	B: Mid season - control	To select the seasonal mode set on the thermostat (0 = MS Not active, 1 = MS Active)								
72	Status	B: Summer - Winter - status	To read the seasonal mode set on the thermostat (0 = Summer, 1 = Winter)	1 bit	C	R	-	T	-	-	Low
73	Enable	B: Summer - Winter - control	To set the seasonal mode on the thermostat (1 = Winter, 0 = Summer). If it is NOT associated with a group then thermostat B will function in Neutral Zone mode.	1 bit	C	-	W	-	U	-	Low
74	Thermostat Off	B: OFF communication - bus - control	This function is useful in the event of faults on the heating system to disable the valves with a 1 bit.	1 bit	C	-	W	-	U	-	Low
75	Dewpoint	B: Thermostat - control	If a 1 bit is sent to this object, the thermostat turn OFF and stop the air conditioner (this works only in air conditioning mode and serves for example to avoid condensation on the floor) - Note: The thermostat requires a cyclical send to this object, with a time that can be set in the parameter "Dewpoint Supervision Time"	1 bit	C	-	W	-	U	-	Low
76	NOT USED										
77	Current Setpoint	B: Setpoint - status	To read the temperature setpoint set on the thermostat. If you want Well-contact Suite to know the setpoint currently set on the thermostats, this object must be linked to a group	2 byte	C	R	-	T	-	-	Low
78	Setpoint Shift	B: Setpoint - status, control	To read and control a temperature shift with respect to the current setpoint (setpoint set by ETS on the thermostat for the various operating modes CMF, STBY, etc.). The temperature shift permitted is limited to the range set by the parameter: Guest Control Permitted. If parameter Guest Control Permitted is set to Off the "Setpoint Shift" object does not shift the active setpoint.	2 byte	C	R	W	T	-	-	Low
79	Winter Comfort	B: Setpoint - status, control	To read and set the Winter Comfort setpoint.	2 byte	C	R	W	T	U	-	Low
80	Winter Standby	B: Setpoint - status, control	To read and set the Winter Standby setpoint	2 byte	C	R	W	T	U	-	Low
81	Winter Energy Saving	B: Setpoint - status, control	To read and set the Winter Economy setpoint	2 byte	C	R	W	T	U	-	Low
82	Winter Protected	B: Setpoint - status, control	To read and set the Winter Antifreeze setpoint	2 byte	C	R	W	T	U	-	Low
83	Summer Comfort	B: Setpoint - status, control	To read and set the Summer Comfort setpoint	2 byte	C	R	W	T	U	-	Low
84	Summer Standby	B: Setpoint - status, control	To read and set the Summer Standby setpoint	2 byte	C	R	W	T	U	-	Low
85	Summer Energy Saving	B: Setpoint - status, control	To read and set the Summer Economy setpoint	2 byte	C	R	W	T	U	-	Low

Continued

C = Communication; R = Read; W = Write; T = Transmission; U = Enable update

Communication objects and ETS parameters

Continued

No.	ETS name	Function	Description	Type	Flag 1						Priority
					C	R	W	T	U	I	
86	Summer Protected	B: Setpoint - status, control	To read and set the Summer Too Hot setpoint (power-off of climate control if the window is opened, for instance)	2 byte	C	R	W	T	U	-	Low
87	NOT USED										
Thermostat B: Valves											
90	Cooling Valve	B: Valve	If the "Valve" parameter is set for 4-pipe systems for valve management in Summer: to be used to control the head of a radiating system or the On/Off valve of a fan coil	1 bit	C	R	-	T	-	-	Low
91	Heating Valve	B: Valve	If the "Valve" parameter is set for 4-pipe systems for valve management in Winter: to be used to control the head of a radiating system or the On/Off valve of a fan coil	1 bit	C	R	-	T	-	-	Low
92	Cooling Valve	B: 2-nd stage cooling	If second cooling stage is enabled to be used for the boost function (cooling) for on/off valve control	1 bit	C	R	-	T	-	-	Low
93	Heating Valve	B: 2-nd stage heating	If second heating stage is enabled to be used for the boost function (heating) for proportional valve control	1 byte	C	R	-	T	-	-	Low
Thermostat B: Fan											
94	Proportional (0-100%)	B: Fan Inputs	Used to set a proportional speed for the fan coil fan (if the selected fan is proportional or 8-bit with 3 speeds) via a supervisor (e.g., touch screen)	1 byte	C	-	W	-	U	-	Low
95	NOT USED										
96	V1 speed	B: Fan Inputs	Used to force activation of fan coil speed V1 (if the selected fan has 3 speeds)	1 bit	C	-	W	-	U	-	Low
97	V2 speed	B: Fan Inputs	Used to force activation of fan coil speed V2 (if the selected fan has 3 speeds)	1 bit	C	-	W	-	U	-	Low
98	V3 speed	B: Fan Inputs	Used to force activation of fan coil speed V3 (if the selected fan has 3 speeds)	1 bit	C	-	W	-	U	-	Low
99	Automatic	B: Fan Inputs	Used to force activation of fan coil speed AUTO (if the selected fan has 3 speeds)	1 bit	C	-	W	-	U	-	Low
100	Proportional (0-100%)	B: Fan Outputs	Used to read the proportional speed of the fan coil fan (if the selected fan is proportional or 8-bit with 3 speeds). This object is used for controlling proportional actuators.	1 byte	C	R	-	T	-	-	Low
101	Off	B: Fan Outputs	Used to read the deactivation status of all 3 speeds (if the selected fan has 3 speeds). The thermostat sends a 1 bit when the fan is off (fan coil speed 0).	1 bit	C	R	-	T	-	-	Low
102	V1 speed	B: Fan Outputs	This is the object to pair with the relay of speed 1 of the fan coil (to read the status of speed V1 of the fan coil, this object can be polled by the bus)	1 bit	C	R	-	T	-	-	Low
103	V2 speed	B: Fan Outputs	This is the object to pair with the relay of speed 2 of the fan coil (to read the status of speed V2 of the fan coil, this object can be polled by the bus)	1 bit	C	R	-	T	-	-	Low
104	V3 speed	B: Fan Outputs	This is the object to pair with the relay of speed 3 of the fan coil (to read the status of speed V3 of the fan coil, this object can be polled by the bus)	1 bit	C	R	-	T	-	-	Low
105	V1 speed	B: Fan Disable	To disable speed V1 (if the selected fan has 3 speeds)	1 bit	C	R	W	T	U	-	Low
106	V2 speed	B: Fan Disable	To disable speed V2 (if the selected fan has 3 speeds)	1 bit	C	R	W	T	U	-	Low
107	V3 speed	B: Fan Disable	To disable speed V3 (if the selected fan has 3 speeds)	1 bit	C	R	W	T	U	-	Low
Thermostat B: window											
108	Window Sensor	B: Window	Object to be paired with the input to which a window-contact is connected so that the thermostat switches to OFF-PROTECTED when the window is opened, depending on whether the mode is Air Conditioning or Heating	1 bit	C	-	W	-	U	-	Low

Continued

C = Communication; R = Read; W = Write; T = Transmission; U = Enable update

Communication objects and ETS parameters

Continued

No.	ETS name	Function	Description	Type	Flag 1						Priority
					C	R	W	T	U	I	
Thermostat B: scenario											
109	Scenario	B: Scenario	To activate a scenario with a 1 Byte message	1 byte	C	-	W	-	U	-	Low
Thermostat B: Auto/Man											
110	Temperature: Automatic/Manual	B: Manual operation	To see whether the guest has altered the thermostat temperature setpoint with respect to the default setting	1 bit	C	R	-	T	-	-	Low
111	Fan coil: Automatic/Manual	B: Manual operation	To see whether the guest has altered the fan coil speed with respect to the default setting	1 bit	C	R	-	T	-	-	Low
112	Temperature: Disable Local operation	B: Manual operation	Activating this object prevents the guest from altering the setpoint temperature by means of the thermostat buttons with respect to the value set by the bus	1 bit	C	-	W	-	U	-	Low
113	Fan coil: Disable Local Operation	B: Manual operation	Activating this object prevents the guest from altering the fan coil speed by means of the thermostat buttons with respect to the value set by the bus	1 bit	C	-	W	-	U	-	Low
Thermostat B: Floor Probe Alarm											
114	Temperature Floor	B: Alarm	If the temperature limitation is active an alarm is sent when the temperature exceeds the set threshold	1 bit	C	R	-	T	-	-	Low
GLOBAL											
115	NOT USED										
116	NOT USED										
117	NOT USED										
119	Input	Input	To control the IN input of the thermostat	1 bit	C	R	-	T	-	-	Low
121	Send scene	Button	Only one scenario can be enabled	1 byte	C	R	-	T	-	-	Low
	Light ON/OFF		Light button function (ON/OFF)								
	Show external temperature		Enable/disable display of temperature from connected temperature sensor.								
	Heating/Air conditioning mode selection		To select between Winter (Heating) = orange color or Summer (Cooling) = azure color								

C = Communication; R = Read; W = Write; T = Transmission; U = Enable update

Number of communication objects	Max. number of group addresses	Max. number of associations
107	254	255

Communication objects and ETS parameters

Reference ETS parameters


General

General parameters


ETS text	Values available [Default value]	Comment
Value shown on the display	0 = Show Room temperature	You can choose whether to view on the display: the temperature measured, the fan coil speed and the valve status, no information, the temperature delta compared to the Setpoint set by the project
	1 = Current setpoint	
	2 = Display Off	
	3 = View Setpoint Difference	
	[0]	
Button Activation	0 = Enable	You can choose whether to make the thermostat buttons operative
	1 = Disable	
	[0]	
Temperature Unit of measure	0 = Celsius	Only for the display
	1 = Fahrenheit	
	[0]	
Mid Season Management	0 = Enable	To invert primary and secondary
	1 = Disable	
	[0]	
Stand-by brightness	0 = Off	Defines the brightness of the display when the thermostat goes on standby
	1 = Low	
	2 = Medium	
	3 = High	
	[0]	
Knob step	0,1°C (0,2 °F)	Allows you to set the set point adjustment step on the knob (in °C or °F)
	0,5°C (1,0 °F)	
	1,0°C (2,0 °F)	
	[0,1°C (0,2 °F)]	

N.B. By activating mid season:

- the valve is deactivated and is never activated;
- the speed settings are activated/deactivated based on a setpoint to reach;
- the 2nd stage of Cooling/Heating is activated based on the setpoint to be reached.



Knob pitch setting



Monochrome mode to blend in the colours of the thermostat with those of the wiring series: Customised colour (RGB setting)

Communication objects and ETS parameters

Digital Input

Digital Input Parameters

ETS text	Values available [Default value]	Comment
Input Function	0 = General Use	If set as "General use", it also sends 0/1 over the bus towards a supervisor
	1 = Window Sensor [0]	
Function (for general use)	0 = Switching on Rising Edge	Rising edge = close contact
	1 = Toggle on Rising Edge	Falling edge = open contact
	2 = Switching on Falling Edge	Switching = sends a 1 bit value (On/Off) on opening and the opposite on closing
	3 = Toggle on Falling Edge	Toggle = on every defined edge (opening or closure), On and then Off is sent to the cycle
	4 = Status Send	To send the contact status upon each switching and also cyclically. [0]
Window Sensor Mode (for thermostat-A and thermostat-B)	0 = Deactivated	Defines whether the window sensor is normally open or closed.
	1 = Normally Open	
	2 = Normally Closed	
	[0]	

Input Function General Purpose Window Switch

A: Window Switch Mode

B: Window Switch Mode

Digital Input - Window Sensor

Input Function General Purpose Window Switch

Function

Value Falling Edge off on

Value Rising Edge off on

Cyclic sending disable enable

Digital Input - General Use

Internal/External Temperature Sensor (Thermostat-A, Thermostat-B)

Sensor parameters

ETS text	Values available [Default value]	Comment
Temperature Offset	-2 °C ... +2 °C	Calibration of thermostat reading (or of average of probes)
	[0]	
Cyclic Send Time	0...30 min.	0=Off. Activates cyclic send of object no. 0 "Internal Sensor" or no. 1 "External Sensor" (both for the thermostat A and for thermostat B)
	[0 = Off]	
Send on Change	0... 1.0 °C	Sets the minimum measured temperature change with respect to the setpoint that will cause the thermostat to send the current value over the bus to a supervisor.
	[0 = Off]	

Temperature Offset

Send Cycle Time

Send Difference

Internal/external temperature sensor

Note: If you use the Well Contact Suite supervision system to update the value displayed by the supervision station of the "A/B Current Temperature" linked to objects nos. 10 and 11, you must enable cyclic send or send on change. In the event of a conjunction of a high number of thermostats, it is not advisable to enable numerous cyclic sends with timing that is too low to avoid overloading the BUS communications.

Communication objects and ETS parameters

Thermostat (A/B)

Guest control permitted

ETS text	Values available [Default value]	Comment
Guest control permitted	0 = Off	Determine how much the guest can change the setpoint from the value set on the thermostat (up/down)
	1 = 1.0 °C	
	2 = 2.0 °C	
	3 = 3.0 °C	
	4 = 4.0 °C	
	5 = 5.0 °C	
	6 = None Limitation	
	[3]	
Setpoint shift step	0.1, 0.2....1	For thermostat A setpoint shift step upon receipt of control on objects 115 and 116
	[1]	

Guest Permit Regulation	3,0 °C
Setpoint shift step	1 °C

Thermostat (A/B)

Current Temperature (A/B)

ETS text	Values available [Default value]	Comment
Temperature sensor weightings	0... 100	For the thermostat's internal sensor, the Vimar wired NTC probe (if present) and the KNX probes, this determines the relative importance for calculating the weighted average of the measured temperatures
	[0]	
Cyclic Send Time	0 = Off	Sets the frequency in minutes with which the thermostat (A/B) must send the measured temperature value (or the weighted average of the probes) over the bus to a supervisor. Activates cyclic send of object no. 10 and 11 "Current Temperature" of thermostat A/B
	11 = 30 min.	
	[0 = Off]	
Send on Change	0 = Off	Sets the temperature difference measured by the thermostat (A/B) that results in the read value (or the weighted average of the probes) being sent over the bus towards a supervisor. Activates cyclic send of object no. 10 and 11 "Current Temperature" of thermostat A/B
	1.0 = 1.0 °C	
	[0 = Off]	

Weight of internal temperature sensor	100
Weight of external temperature sensor	0
Weight of outside temperature 1	0
Weight of outside temperature 2	0
Weight of outside temperature 3	0
Weight of outside temperature 4	0
Weight of outside temperature 5	0
Weight of outside temperature 6	0
Weight of outside temperature 7	0
Weight of outside temperature 8	0
Current Temperature	
Send Cycle Time	off
Send Difference	off

Current temperature (A/B)

Communication objects and ETS parameters

Setpoint (A/B)

Setpoint parameters

ETS text	Values available [Default value]	Comment
Mode at bus power on	1 = Comfort	Thermostat operating mode at bus power on
	2 = Standby	
	3 = Energy saving	
	4 = Protect	
	255 = Last Mode Selected [255]	
Time between Heating and Cooling	1 min.	To avoid the formation of condensation with radiating systems during changes of season
	10 min.	
	15 min.	
	20 min.	
	25 min.	
	30 min.	
	45 min.	
	60 min.	
[30]		
Dewpoint Supervision Time	0 = Off	Sets the time within which the thermostat must receive a message to the "Dewpoint" object from a device connected to a humidistat.
	30 sec	
	1 min.	
	2 min.	
	3 min.	A bit set to "1" will stop heating/air conditioning and set to "0" will cause it to restart. If messages have not arrived, when this time has elapsed heating/air conditioning will restart
	4 min.	
	5 min.	
	10 min.	
	15 min.	
	20 min.	
	25 min.	
30 min.		
[0 = Off]		
Cyclic Send Time	0 = Off	Sets the time for cyclic sending of temperature setpoint over bus towards a supervisor
	30 sec.	
	1 min.	
	2 min.	
	3 min.	
	4 min.	
	5 min.	
	10 min.	
	15 min.	
	20 min.	
	25 min.	
	30 min.	
	[0 = Off]	
Send on Change	0 = Off	Sets the minimum temperature change made by the guest with respect to the setpoint that results in the current setpoint being sent over the bus towards a supervisor
	0.1 °C	
	0.2 °C	
	0.3 °C	
	0.4 °C	
	0.5 °C	
	0.6 °C	
	0.7 °C	
	0.8 °C	
	0.9 °C	
	1.0 °C	
[0 = Off]		
Reset Setpoint Shift in Economy Mode	Yes	By selecting "Yes", when the thermostat goes into Energy Saving (Economy) mode, the setpoint set by the user in Comfort and Standby mode is reset to the design default value. This function is useful for hotel applications and with the Well Contact Suite supervision software.
	No	
	[Yes]	

Mode after bus return last selected mode ▼

Time Between Heating and Cooling 30 min ▼

Supervision Time of Dew Point off ▼

Current Setpoint

Send Cycle Timer off ▼

Send Difference off ▼

Reset Setpoint Shift in Economy Mode Yes No

Setpoint parameters

Important: The "Time between Heating and Cooling" parameter is the wait time it takes for the thermostat to switch from summer-winter and vice versa. This parameter is especially useful in some underfloor radiant systems where you set a high time value to prevent the formation of condensation; this applies especially when the thermostats work with a neutral zone and so there could be multiple seasonal changes in a single day. If instead, depending on the type of system, you want a faster response of the thermostat, it is necessary to reduce the value of this parameter.

Communication objects and ETS parameters

Temperature Setpoint (A/B)


Sensor parameters

ETS text	Values available [Default value]	Comment
Winter Comfort Setpoint	[20]	See "Range" table
Winter Standby Setpoint	[18]	See "Range" table
Winter Energy Saving Setpoint	[15]	See "Range" table
Antifreeze	0 = Control Off	If you set "On" you can set the temperature the thermostat goes to in "Protected" mode; if you set "Off", when the thermostat is in "Protected" mode it will turn off temperature control and will not send the current setpoint temperature
	1 = Control On	
	[1 = 011]	
Summer Comfort Setpoint	[25]	See "Range" table
Summer Standby Setpoint	[28]	See "Range" table
Summer Energy Saving Setpoint	[30]	See "Range" table

Continued

Setpoint range

Temp. °C	Temp. °C	Temp. °C	Temp. °C
5	16	27	38
6	17	28	39
7	18	29	40
8	19	30	41
9	20	31	42
10	21	32	43
11	22	33	44
12	23	34	45
13	24	35	
14	25	36	
15	26	37	



CAUTION: When the thermostat is in Neutral Zone mode, the breadth of this must be progressively increasing for the different operating modes of Comfort (minimum neutral zone breadth), Standby, Energy Saving and Protected. This setting made with ETS ensures that, when the thermostat changes operating mode, the active setpoint is always at a suitable value and the thermostat does not start cooling if it was heating before or vice versa, causing considerable energy consumption.

Continued

ETS text	Values available [Default value]	Comment
Too hot	0 = Control Off	If you set "On" you can set the temperature the thermostat goes to in "Protected" mode; if you set "Off", when the thermostat is in "Protected" mode it will turn off temperature control and will not send the current setpoint temperature
	1 = Control On	
	[1 = On]	

Note: In the case of a 4-pipe system, the winter setpoint cannot take a higher value than the summer setpoint.

Winter

Setpoint Comfort Winter 20 °C

Setpoint Standby Winter 18 °C

Setpoint Economy Winter 15 °C

Antifreeze Regulation Off Regulation On

Setpoint Antifreeze 5 °C

Summer

Setpoint Comfort Summer 25 °C

Setpoint Standby Summer 28 °C

Setpoint Economy Summer 30 °C

Too hot Regulation Off Regulation On

Temperature setpoint parameters

Communication objects and ETS parameters

Window sensor (A/B)

Sensor parameters

ETS text	Values available [Default value]	Comment
Window sensor delay	0 = Off	Sets the time delay that heating/air conditioning stops after window open detection
	5 sec	
	10 sec	
	20 sec	
	45 sec	
	60 sec	
	90 sec	
	120 sec	
	180 sec	
	240 sec	
	300 sec	
	[30]	

Delay for window switches

30 sec ▼

- off
- 5 sec
- 10 sec
- 20 sec
- 30 sec ✓
- 45 sec
- 60 sec
- 90 sec
- 120 sec
- 180 sec
- 240 sec
- 300 sec

Window sensor (A/B)

Control parameters

ETS text	Values available [Default value]	Comment
Control Temperature	0 = Control On/Off	Set according to the type of control required for the heating/air conditioning system
	1 = Integral Band	
	2 = Proportional/Integral Band	
	[0]	
Value Proportional Cooling	1.0 °C	To be set according to the characteristics of the system and the room (consult a heating engineer)
	1.1 °C	
	1.2 °C	
	1.3 °C	
	1.4 °C	
	1.5 °C	
	1.6 °C	
	1.7 °C	
	1.8 °C	
	2.0 °C	
	2.2 °C	
	2.5 °C	
	3.0 °C	
	3.5 °C	
	4.0 °C	
4.5 °C		
5.0 °C		
[3.0 °C]		

Temperature Regulation

Regulation On/Off ▼

Differential coefficient

0,2 °C ▼

Control On/Off (A/B)

Communication objects and ETS parameters

Proportional/Integral (PI) control

This type of control uses a more advanced algorithm that keeps the temperature inside the room more stable, increasing comfort. This algorithm works by switching the system on and off so as to be like a gradual increase or decrease in the system's thermal (or refrigerating) power. To obtain optimal performance you need to perform the calibration according to the type of room and heating system.


Define the variables:

- Ta = room temperature
- Sp = current setpoint
- Kp = coefficient of the proportional component
- Ki = coefficient of the integral component
- Bp = proportional band
- Ti = integrative time


the algorithm is characterised by the following parameters:

- **Proportional band:** used to calculate the coefficient $K_p = 100 / B_p$ and corresponds to the breadth of the proportional control band. Starting from the set temperature, this value is the temperature range in which the system power goes from 0% to 100%. *For example:* with the (heating) temperature set to 20.0°C and Band (P) =4.0°C, the thermostat runs the heating system at 100% when Ta is $\leq 16.0^\circ\text{C}$; as this temperature increases, the system power is consequently lowered down to 0% when Ta reaches 20°C. The value must be set taking account of the thermal capacity of the room to control; in general, it is recommended to use small values for rooms with a good level of thermal insulation and vice versa.
- **Integrative time:** used to calculate the coefficient $K_i = K_p / T_i$ and corresponds to the time passed which, when equal to the deviation from the setpoint (error), the integrative component generates a contribution equal to that generated by the proportional component. The integral contribution reduces the error on full operation if thermal energy is lost in the room to be controlled, as this contribution increases according to the time during which the setpoint is not reached. If this value is not set correctly, it can cause transients with variations around the setpoint or it may take longer to reach the setpoint.

Proportional integral PWM: PI control with On/Off valve



Continuous integral proportional: PI control with proportional valve



The parameters of the proportional and integral coefficients Kp and Ki are set using the ETS software: the proportional coefficient Kp for heating corresponds to the "Heating Proportional Value" parameter while the coefficient for cooling is set using the "Cooling Proportional Value" parameter. The integral time Ti is set with the "Heating Integral Value" and "Cooling Integral Value" parameters for heating and cooling, respectively.

The PI control parameters should be set according to the type of heating or cooling system used, the size of the room and its thermal insulation.

IMPORTANT: Generally, when using fan coils, PI control is not used. The valve is typically managed with On/Off control and On/Off valve or proportional valve (0%-100%); the fine adjustment is then made using the fan speed.

Communication objects and ETS parameters

Continued

ETS text	Values available [Default value]	Comment
Integral Cooling Value	5 min.	
	6 min.	
	7 min.	
	8 min.	
	9 min.	
	10 min.	
	12 min.	
	15 min.	
	17 min.	
	20 min.	
	25 min.	
	30 min.	
	40 min.	
	50 min.	
	60 min.	
	90 min.	
120 min.		
	[20 min.]	
Proportional Heating Value	0 = Off	To be set according to the characteristics of the system and the room (consult a heating engineer)
	1.0 °C	
	1.1 °C	
	1.2 °C	
	1.3 °C	
	1.4 °C	
	1.5 °C	
	1.6 °C	
	1.7 °C	
	1.8 °C	
	2.0 °C	
	2.2 °C	
	2.5 °C	
	3.0 °C	
	3.5 °C	
	4.0 °C	
4.5 °C		
5.0 °C		
	[3.0 °C]	
Integral Heating Value	0=Off	
	5 min.	
	6 min.	
	7 min.	
	8 min.	
	9 min.	
	10 min.	
	12 min.	
	15 min.	
	17 min.	
	20 min.	
	25 min.	
	30 min.	
	40 min.	
	50 min.	
	60 min.	
90 min.		
120 min.		
	[20 min.]	
Differential Coefficient	0.1... 1.0 °C	For On/Off type control: set the thermostat (A/B) hysteresis that determines activation/deactivation of the system with reference to the difference between the setpoint and the measured temperature
	[1=0.2]	

Temperature Regulation	Integral Band
Integral Value Cooling	20 min
Integral Value Heating	20 min
Integral band (A/B)	
Temperature Regulation	Proportional/Integral Band
Proportional Value Cooling	3,0 °C
Integral Value Cooling	20 min
Proportional Value Heating	3,0 °C
Integral Value Heating	20 min
Proportional/integral band (A/B)	


Communication objects and ETS parameters

Valve (A/B)


Valve parameters

ETS text	Values available [Default value]	Comment
System Layout	0 = 2-Pipe Circuit On/Off	Select according to the type of installed system
	1 = 4-Pipe Circuit On/Off	
	2 = 2 Pipes Proportional	
	3 = 4 Pipes Proportional	
	[0]	
Cyclic Send Time in Cooling	0 = Off....30 min. [0]	Sets the valve status send time to the associated actuators (parameter required for certain types of valves, for example Theben proportional valves, etc.)
Cyclic Send Time in Heating	0 = Off....30 min. [0]	

Installation of 2-pipe fan coil solenoid valve



Installation of 4-pipe fan coil solenoid valve



Plant Topology: 2 Tubes Circuit On/Off
Send Cycle Time: off
2-Pipe Circuit On/Off (A/B)

Plant Topology: 4 Tubes Circuit On/Off
Cooling Valve: off
Send Cycle Time Cool: off
Heating Valve: off
Send Cycle Time Heat: off
4-Pipe Circuit On/Off (A/B)

Plant Topology: 2 Tubes Proportional
Send Cycle Time: off
Proportional 2-Pipe Circuit (A/B)


Plant Topology: 4 Tubes Proportional
Cooling Valve: off
Send Cycle Time Cool: off
Heating Valve: off
Send Cycle Time Heat: off
Proportional 4-Pipe Circuit (A/B)

Communication objects and ETS parameters

2nd Heating/Cooling Stage (A/B) "Boost"

The second stage is used to control a second heating or cooling source that allows the "boost" function. The "boost" function enables the second auxiliary source when the current temperature differs from the current setpoint by more than the set threshold.

In this way, the main heating/cooling stage is assisted by the auxiliary source to reach the desired setpoint value faster. This feature is particularly useful for improving comfort in dynamic lens systems such as underfloor systems.



2nd Stage Parameters

ETS text	Values available [Default value]	Comment
2 nd Stage Cooling Valve	Disabled	Second cooling stage off
	Enable 2-point On-Off Control	Control with object that sends on/off for valve status
	Enable 2-point Control 0-100%	Control with object that sends 0% for valve off status and 100% for valve on status
	Cooling Threshold: - 0.5°C - 1.0°C - 1.5°C - 2.0°C - 2.5°C - 3.0°C - 3.5°C - 4.0°C - 4.5°C - 5.0°C	Value of the trigger threshold in cooling mode
2 nd Stage Heating Valve	Disabled	Second heating stage off.
	Enable 2-point On-Off Control	Control with object that sends on/off for valve status
	Enable 2-point Control 0-100%	Control with object that sends 0% for valve off status and 100% for valve on status
	Heating Threshold: - 0.5°C - 1.0°C - 1.5°C - 2.0°C - 2.5°C - 3.0°C - 3.5°C - 4.0°C - 4.5°C - 5.0°C	Value of the trigger threshold in heating mode

Cooling 2^o stage

Heating 2^o stage

2nd Stage Disabled (A/B)

Cooling 2^o stage

Threshold Cooling

Heating 2^o stage

Threshold Heating

2nd Stage - Enable 2-point On-Off Control (A/B)

Cooling 2^o stage

Threshold Cooling

Heating 2^o stage

Threshold Heating

2nd Stage - Enable 2-Point Control 0-100% (A/B)

Communication objects and ETS parameters

Fan (A/B)

Fan parameters

ETS text	Values available [Default value]	Comment
Type	0 = Off	No thermostat controlled fan coil. Disables the graphics for the fan on the thermostat too. Useful when controlling only the solenoid valve for a radiator system
	1 = Three Speeds Fan coil	Fan coil with 3 speeds
	2 = Proportional (0 - 100%)	Proportional-speed fan coil
	[1]	
Maximum Fan Speed	0	Sets maximum fan coil speed. Set "0" to control only the solenoid valve for a radiator system
	1	
	2	
	3	
	[3]	
Threshold for Fan Speed. 2	0.2 °C	Sets the difference between the current temperature and the setpoint that triggers start of speed V-2
	0.3 °C	
	0.5 °C	
	1.0 °C	
	1.5 °C	
	2.0 °C	
	2.5 °C	
	3.0 °C	
	3.5 °C	
	4.0 °C	
[1.0]		
Threshold for Fan Speed. 3	0.2 °C	Sets the difference between the current temperature and the setpoint that triggers start of speed V-3
	0.3 °C	
	0.5 °C	
	1.0 °C	
	1.5 °C	
	2.0 °C	
	2.5 °C	
	3.0 °C	
	3.5 °C	
	4.0 °C	
[2.0]		
Fan Speed Hysteresis	0.1 °C	Hysteresis for the above-mentioned speed values
	0.2 °C	
	0.3 °C	
	0.4 °C	
	0.5 °C	
	0.6 °C	
	0.7 °C	
	0.8 °C	
	0.9 °C	
	1.0 °C	
[1=0.1]		
Switching Time between Speeds (min)	0...255	Time, in minutes, it takes to switch from one speed to another.
	[2]	

Continued

IMPORTANT: If you set "Switching Time between Speeds (min)" to 0 and leave a low value of "Fan Speed Hysteresis" (<0.5°C) there may be, near the speed change threshold temperatures, continual and repeated switching of the fan coil speeds that could damage it.

Continued

ETS text	Values available [Default value]	Comment
Time in Fan Man. Mode (min.)	0...255	Duration of "Manual Forcing" for the fan speed if the guest has forced the speed; after this time the thermostat returns to automatic mode. If the parameter is set to "0" it is interpreted as "Time = infinite" and the fan speed, set manually, stays on. To restore automatic operation the guest must return the fan speed to AUTO by manually operating on the thermostat display.
	[0]	
Objects	0 = 1-bit object	Select type of object (1 bit for On/Off, 8 bits for proportional 1-100%)
	1 = 8-bit object (1-100%)	
Cyclic Send Time	0 = Off	Set cyclical sending over the bus for the fans
	11 = 30 min.	
Threshold for Speed at 100%	[0 = Off]	Absolute difference between setpoint and current temperature above which the speed goes to 100%
	0 = 2 °C	
	1 = 3 °C	
	2 = 4 °C	
	4 = 5 °C	
[4]		
Minimum Fan Speed	0 = 10%	Minimum operating speed on fan activation
	1 = 20%	
	2 = 30%	
	3 = 40%	
	4 = 50%	
[0]		
Fans independent of the valve	Yes	Possibility of controlling the fans even with the valve off
	No	
[No]		
Automatic speed disabling	Yes	Possibility of disabling the fan button on the display and objects 43 and 90 (Automatic)
	No	
[No]		
Fan zero speed disabling	Yes	Inhibits the ability to turn off the fan
	No	
[No]		

Communication objects and ETS parameters

Type: Three speed fan coil

Maximum Fan Speed: 3

Threshold value for fan speed 2: 1,0 °C

Threshold value for fan speed 3: 2,0 °C

Hysteresis of fan speed: 0,1 °C

Time for switching between speeds (min): 2

Time in manual fan mode (min): 0

Objects: 1 Bit object 8-Bit Object (1-100%)

Send Cycle Time: off

Fans independent of the valve: Yes No

Automatic fan disabling: Yes No

Fan zero speed disabling: Yes No

Three Speed Fan coil (A/B)

Type: Three speed fan coil

Maximum Fan Speed: 3

Threshold value for fan speed 2: 1,0 °C

Threshold value for fan speed 3: 2,0 °C

Hysteresis of fan speed: 0,1 °C

Time for switching between speeds (min): 2

Time in manual fan mode (min): 0

Objects: 1 Bit object 8-Bit Object (1-100%)

Send Cycle Time: off

Fans independent of the valve: Yes No

Automatic fan disabling: Yes No

Three Speed Proportional (A/B)

Type: Proportional (0-100%)

Temperature for 100%: 5 °C

Minimum Fan Speed: 10%

Time in manual fan mode (min): 0

Send Cycle Time: off

Fans independent of the valve: Yes No

Automatic fan disabling: Yes No

Proportional (A/B)

Manual operation of the fans

The user selects the speed used by the thermostat only when the valve is on; if the valve is off at the time of selection, the thermostat saves the setting and uses it again the next time the valve is on. On the display, the fan speed changes from "AUTO" to "OFF".

The selection made by the user remains active until the end of the time (in minutes) set by the "Time in Manual Fan Mode (min)" parameter or the fan speed is set manually onto "AUTO" with the button or remotely via the communication object.


43	Automatico	A: Ingressi Ventilatore
90	Automatico	B: Ingressi Ventilatore

Caution: If the "Time in Manual Fan Mode (min)" parameter is equal to 0 it means that the manual operation of the fan is never turned off by time.

Automatic three-speed fan coil operation

In the case of a three-speed fan coil in "AUTO" mode, the fan coil speed is controlled automatically by the thermostat. The speed automatically goes from the higher to the lower speed gradually as the measured temperature approaches the value set as the setpoint. The threshold to determine the speed to set is linked to the following parameters: "Threshold for the Speed of Fan 2" and "Threshold for the Speed of Fan 3" while speed 1 is active when the valve is turned on and the "Switching time between speeds (min)" has passed.



An example of operation is shown in the following figure where SV2 and SV3 are respectively "Threshold for the Speed of Fan 2" and "Threshold for the Speed of Fan 3"; ΔTR is instead the "Differential Coefficient" of the on/off setting.



Note: In the example shown in the figure, the effect of the "Fan Speed Hysteresis" parameter was overlooked and the "Switching time between speeds" parameter was set = 0.


When the measured temperature reaches the setpoint the thermostat switches off the fan, sends a 1 bit on the Bus for object no. 45 or no. 92 "Off - Fan Outputs" (V0), switches on V0 and switches off V1. When the temperature deviates from the desired value, the valve is turned on and the speed V1, after the value of "Switching time between speeds", is activated. In the following example figures, this parameter is set to 0.

N.B.: For reasons tied to the safety of systems, if the valve is active the user will be unable to set "OFF" from the thermostat. It will therefore be necessary to turn off the valve by setting the thermostat to another mode or by modifying its setpoint.





Switching Time Between Speeds

This is the time you need to wait for the activation of the speed after switching on the valve (allows the fan coil battery to reach the correct temperature before circulating the air). This parameter is also used between one speed change and another to avoid continual speed switching near the thresholds.



Proportional fan coil operation

Proportional fan operation is similar to that of the three-speed fan coil. When the valve is OFF the proportional speed is equal to 0%; when the valve is ON the value of the proportional speed depends on the difference between the setpoint and the temperature measured in the room. The greater the difference, the higher the set proportional value of the speed. When this difference exceeds the value of the "Threshold for Speed at 100%" the proportional output of the fan is set to the highest possible speed that is 100%; when the difference is minimal the proportional speed is set to "Minimum Fan Speed". The operation of the proportional fan, as for the three speeds, can be set automatically or, in manual mode, to the value invoked by the thermostat button or set by the object "Proportional (0-100%) - Fan Inputs"



N.B.: For reasons tied to the safety of systems, if the valve is active the user will be unable to set "OFF" from the thermostat. It will therefore be necessary to turn off the valve by setting the thermostat to another mode or by modifying its setpoint.

Communication objects and ETS parameters

Scenario (A/B)

16 scenarios are available. 16 different scenarios can therefore be saved on the device output. With **Enable Scenario Learning** you can also set the status of the output for the desired scenario with a message from the bus (scene learn).

Scenario parameters

ETS text	Values available [Default value]	Comment
Scenario Learning	0 = disable 1 = enable [0]	To enable scenario thermostat learning
Scenario	0=disabled 1=Comfort 2=Standby 3=Energy saving 4=Protected [0]	To define the operating mode when the scenario is called up.
...Scenario 16	0=disabled 1=Comfort 2=Standby 3=Energy saving 4=Protected [0]	To define the operating mode when the scenario is called up.

Scene learning

disable enable

Scene 1	disabled
Scene 2	disabled
Scene 3	disabled
Scene 4	disabled
Scene 5	disabled
Scene 6	disabled
Scene 7	disabled
Scene 8	disabled
Scene 9	disabled
Scene 10	disabled
Scene 11	disabled
Scene 12	disabled
Scene 13	disabled
Scene 14	disabled
Scene 15	disabled
Scene 16	disabled

Scenario parameters (A/B)

Communication objects and ETS parameters

Temperature Protection (A/B)

This function is used to limit the temperature of the area controlled by the thermostat

Temperature Protection Parameters

With the "Temperature Channel" parameter you select the temperature to be monitored; when, in heating, it exceeds the value selected with the "Temperature Limit" parameter, the thermostat changes its operating mode and switches OFF sending an alarm signal with the object *Floor Temperature Alarm*.

The thermostat comes out of the alarm condition when the temperature drops below the set threshold and the user changes the thermostat operating mode.

The typical application for this function is that of limiting the maximum temperature of the floor.

Temperature Channel	disabled
Temperature Limit	35

Temperature Protection (A/B)

ETS text	Values available [Default value]	Comment
Temperature Channel	0 = Disabled	Limitation disabled
	1 = Internal Sensor	The internal sensor is used for temperature limitation
	2 = External Sensor	The external sensor is used for temperature limitation
	3 = External Temperature 1	The External Temperature 1 is used for temperature limitation
	4 = External Temperature 2	The External Temperature 2 is used for temperature limitation
	5 = External Temperature 3	The External Temperature 3 is used for temperature limitation
	6 = External Temperature 4	The External Temperature 4 is used for temperature limitation
	7 = External Temperature 5	The External Temperature 5 is used for temperature limitation
	8 = External Temperature 6	The External Temperature 6 is used for temperature limitation
	9 = External Temperature 7	The External Temperature 7 is used for temperature limitation
	10=External Temperature 8	The External Temperature 8 is used for temperature limitation
	[0]	
Temperature Limit	10...70 °C	Limit of the temperature channel beyond which the limitation trips
	[35]	

FAQ

1. Which thermostat objects must be used in the ETS project? For each one, should a dedicated ETS group be created or should "common groups" be created?

For the objects listed below, you must create a separate group for each datapoint of each thermostat:

In general:

- Thermostat A: 13 - 63.
- Thermostat B: 64 -113.

Specifically:

- 12 if Thermostat B is present.
- 39 if it is a 4 PIPE system and there is a COOLING valve. 90 for thermostat B.
- 43 if proportional fan coil present. 94 for Thermostat B.
- 57 if a window contact that must deactivate climate control is present, 108 for Thermostat B.

Note.

You could also create a general group with the Summer/Winter control of all the thermostats (DATAPOINT 22 for Thermostats A and 72 for Thermostats B), but if it is a system in which there is the Well-contact Suite supervision software we recommend that you create a group for each single Thermostat A and for each single Thermostat B.

2. What does the "Thermostat Mode" object represent?

It refers exclusively to the **mode the thermostat is currently in** (or the mode you want to put it into given that the corresponding object is also present in write mode).

It does not indicate whether it is summer or winter. The possible options are:

- 01 = Comfort
- 02 = StandBy
- 03 = Economy
- 04 = Protect/Off

To see whether the thermostat is in Off mode you can go and read object 16 "Off A: Mode - control" or object 67 "Off B: Mode - control" which will answer 1 if the thermostat is Off or 0 if it is in another operating mode.

3. What difference is there between the "Protected" object and "Off" in "Antifreeze-Too Hot" operation?

The "Protected" object is used and acts as Off in the event that the "Temperature Setpoint" parameters and the items "Antifreeze" and "Too Hot" are set to "Control Off". So in this case when the object "Protected" is activated, the thermostat entirely disables temperature control and does not even send its current setpoint over the bus. In normal installations it is therefore recommended to set "Control On" on the parameters "Antifreeze" and "Too Hot" and to set the corresponding two temperatures. This avoids the risk of frozen pipes in the winter and excessive room overheating in the summer. The "Off" mode on the other hand also inhibits "Too Hot" and "Antifreeze" and should never be used in normal installations. The "Off Mode" object turns off the thermostat even if the temperature falls below zero (i.e. it does not activate Heating/Air conditioning). It is advisable to use the "Protected" object, which switches the thermostat to Off or protected (Antifreeze) depending on how the relevant parameters are set (summer or winter).

4. What is the function of the "Thermostat Off" object and what applications can it have?

Thermostats have various objects created for operation with our Well-contact Suite hotel software. The "Thermostat Off" object blocks thermostat bus communication (both reception and transmission). This function is dedicated to Vimar supervision software.

5. What is the function of the "Off" mode and what applications does it have?

The "Off Mode" object turns off the thermostat even if the temperature falls below zero (i.e. it does not activate Heating/Air-conditioning). It is advisable to use the "Protected" object, which switches the thermostat to Off or protected (Antifreeze) depending on how the relevant parameters are set (summer or winter).

6. What is the function of the "Comfort" object?

Unlike the "Energy Saving", "Protected" and "Off" objects, which do not permit the sending of a "0" bit, if the "Comfort" object is set to "1", the thermostat switches to **comfort mode** at the design temperature or at the custom temperature previously set by the guest. If this object is set to "0" the thermostat switches to **standby mode** (at the design temperature or at the custom temperature previously set by the guest).

7. What is the function of the "Summer Protected" object?

It is the **protected mode** setpoint in air conditioning operation. It corresponds to protected mode in heating operation (with air conditioning operation it cools if the temperature exceeds the setpoint whereas with heating operation it heats if the temperature falls below the setpoint).

8. On thermostats 20542, 16922 and 14522 a single bit was used to activate/deactivate antifreeze. What is used now?

The "Protected" object (summer or winter) is used.

Note.

Antifreeze (or its analogue "Too Hot") must be active in the object parameters so as not to obtain an Off.

9. On thermostats 20542, 16922 and 14522, to deactivate "Antifreeze" mode it was sufficient to send a "0". What needs to be done with the new thermostats? Do you need to change mode, for instance "Economy"?

Yes, the installer decides whether the user can turn the system off or set it to "Antifreeze" mode. Depending on the set ETS parameters, the thermostat switches to "Antifreeze" mode and returns to the previous mode only when the window is opened and closed, whereas if the thermostat is set to "Protected" mode from the bus, it will subsequently be necessary to change the mode.

FAQ

10. On thermostats 20542, 16922 and 14522, a single bit was used to read the antifreeze status; in supervision single bits ("0" or "1") and not bytes are required. Where is this object/status to be found?

The KNX system uses the 1-byte object "*Thermostat Mode*" to read the status of the thermostat. If you do not want to use the Byte, you can set the 1-bit mode change object to read. However, this is not the ideal solution because the bits will have to be read explicitly given that the information is not sent automatically.

11. Are there any particular precautions to take when using the 0-100% proportional valve control?

Never use the "*Control Value*" object. This is a debug object left inside the application for KNX certification purposes. In this specific case replace it with "*Cooling Valve*" to obtain the desired function.

However, some types of valves with proportional control require a cyclic refresh of the control value. **In this case it is necessary to activate cyclic sending of the control value to the valve.** To control the proportional solenoid valves you must use the "*Cooling/Heating Valve*" object in read/write mode (which appears only for "2-Pipe Proportional" systems, selected by the parameter "*Valves*") or objects "*Cooling Valve*" and "*Heating Valve*" will appear if "*System Type*" is set with the "*Proportional 4-Pipe Circuit*" parameter.

12. We need to have a group that goes to "0" when the thermostat is set to "Off" (by the guest or the supervisor) and returns to "1" when the thermostat is returned to "CMF". How can we do this?

This is an application that allows the input of a Daikin with KNX interface to be forced so that it turns the machine off if the thermostat is Off and back on if it is "CMF" without necessarily starting the system (heating is subsequently activated depending on the messages sent by the thermostat to the valve). In practice the guest wants to use the thermostat for On/Off control of a device that has its own temperature control function.

To do this you have to use an object (such as a KNX logic) that sends an On/Off message according to the thermostat mode (using the "*Mode*" object).

13. How should a window's N.C. contact be managed when it is connected to the thermostat for window open signalling?

The input to which the window contact is connected must be set with the "*Status Send*" function so that one message is sent when it is opened and another one when it is closed. If an N.C. contact is used, it will be necessary to set "*Off*" for the falling edge (opening of window and contact) and "*On*" for the rising edge (closing of the window and contact). If the contact is an N.O. type, the two parameters must be set respectively to "*On*" and "*Off*" (when the window is opened the contact is closed and vice versa). If you set the input as "*Window Sensor*", opening the window will stop the thermostat writing an "04" byte (antifreeze) to the datapoint "*Mode status*" and "00" to the datapoint "*Cooling/Heating Valve*" (closes the valve); closing the window will set the previous status; you can also choose a delay time for opening the window after which the thermostat will stop. If together with

this internal thermostat management you also want a "0" bit to be sent to the bus when the window is opened and a "1" bit when it is closed, you must set the thermostat IN input as "*General Use*" so as also to display object no. 110 "*Input*". If the window contact is connected to the thermostat's input, this new object must be associated with a group with the "*Window Sensor*" object, whereas if you use the IN input of another KNX device this will be associated with the "*Window Sensor*" object.

14. Which functions are considered most important for use of the thermostats on hotel systems with the Well-contact Suite management/supervision (and other) software?

a. *Current Temperature*: this is useful for displaying the thermostat temperature in the software (it is advisable to set cyclic sending amongst the parameters; to be considered in the event of a large number of devices).

b. *Thermostat Mode* or alternatively *Comfort*, *Energy Saving*, *Protection*: these are important for sending thermostat operating mode controls via Well-contact Suite.

c. *Thermostat Mode - status*: this is important to see the current operating mode of the thermostats in the software.

d. *Summer/Winter status*: this is important to see the current seasonal operating mode of the thermostats in the software.

e. *Enable Summer/Winter*: this is essential for sending seasonal thermostat operating mode controls via Well-contact Suite software.

f. *Current Setpoint*: this is useful for displaying the set thermostat temperature in the software (it is advisable to set cyclic sending amongst the parameters; to be considered in the event of a large number of devices).

g. *Winter Comfort Setpoint*, *Winter Standby Setpoint*, *Winter Energy Saving Setpoint*, *Winter Protected Setpoint*, *Summer Comfort Setpoint*, *Summer Standby Setpoint*, *Summer Energy Saving Setpoint*, *Summer Protected Setpoint* (objects from 28 to 35 and from 79 to 86): they are useful for displaying and setting the various "*Basic Setpoints*" in the two seasonal operating modes in the software.

Note. To be able to view the values, you have to set the read flag for these properties manually in ETS.

h. Management case studies Heating/air conditioning speed for thermostats:

Proportional Three Speed Control:

1. *Proportional (0-100%) - Fan Inputs*: useful for sending the proportional speed maximum value.
2. *Proportional (0-100%) - Fan Outputs*: useful for displaying the proportional speed maximum value in the software.

On/Off management:

1. *Speed V1 - Fan Inputs*, *Speed V2 - Fan Inputs*, *Speed V3 - Fan Inputs*, *Automatic - Fan Inputs*: useful for sending speed force controls to the thermostat or for forcing automatic control.
2. *Off - Fan Outputs*, *Speed V1 - Fan Outputs*, *Speed V2 - Fan Outputs*, *Speed V3 - Fan Outputs*: useful for displaying the current speed of the fan coil.
3. *Speed V1 - Disable Fan*, *Speed V2 - Disable Fan*, *Speed V3 - Disable Fan*: useful for sending speed disable controls.

FAQ

- i. Window Sensor (objects 57 and 108): viewing the status of the window combined with the thermostat on the supervision software (for example on the computer of a hotel reception desk) requires you to:
 1. Set the input contact as "General use" and use it as an open window sensor;
 2. Assign the address of the desired group to the "Window Sensor" object
 3. Assign to this address the "Contact" Address/Object type inside the Well-Contact Suite software.
- l. *Temperature*: Automatic/Manual: useful for displaying whether the setpoint has been set from software or manually using the thermostat buttons.
- m. *Fan coil*: Automatic/Manual: useful for displaying whether the current fan coil speed is managed automatically by the thermostat or has been forced.
- n. *Temperature*: Disable Local Operation: useful for displaying and sending controls from software regarding whether or not it is possible to set the current setpoint on the thermostat manually.
- o. *Fan coil*: Disable Local Operation: useful for displaying and sending controls from software regarding whether or not it is possible to set the speed manually from the thermostat.

15. To perform supervision of thermostats using Vimar Well-contact Suite software, what communication objects need to be set?

YOU have to set to "Read" the relevant flags of objects from 28 to 35 and from 79 to 86 for each 02972 thermostat.

16. What is the parameter "Time in Manual Fan Mode" used for?

It is a time indicated in the parameters for which the thermostat remains in "Manual forcing" if the guest has manually forced the temperatures or speed of the fan coil: when this time has elapsed the thermostat returns to automatic. If the parameter is set to "0" it is interpreted as "Time = infinite" and the manual forcing stays on.

17. An object is needed that goes to "1" if one of the 3 speeds is activated and returns to "0" if V 1/2/3 are deactivated.

Use the object "Cooling/Heating valve".

18. Is it possible to take an object to "0" when a speed V-0 is set from the thermostat?

No, it is not possible to set the speed V-0 manually.

19. Is the object "Thermostat Mode - Mode" (object 17 and 68) usable only by Well-Contact Suite or also by other supervision software?

The object "Thermostat Mode - Mode" is a KNX standard object, with coding defined by the standard (HVAC Operating Mode 20.102), therefore it can also be used by other supervision software; there is also the related object for reading the mode (objects 18 and 69).

- 0 = Automatic
- 1 = Comfort
- 2 = StandBy
- 3 = Economy
- 4 = Protection
- 5-255 = Reserved values



20. Is it possible to manage a general valve if there is more than one thermostat?

This function is possible only with a logic module. It is also possible to use a Well-contact Suite functional logic, which will operate only if the supervision software is active and communicating with the bus.

21. Is it possible to control a proportional-type fan coil with one or two supply values?

The thermostat normally controls supply at three levels of intensity: 33%, 67%, 100%. As can be seen in the following image, setting the maximum speed to 1 or 2 results in one or two thresholds (respectively 33% or 33-67%). Other supply level settings are not possible.

For the TACTIL thermostat 02972 you can still control the proportional fan coil with minimum speed settable from 10% to 50% and with maximum speed up to 100%.



FAQ

22. Is it possible to control an On/Off type radiant heating system and a fan coil air-conditioning system with 3 speeds?

You have to work prevalently with the thermostat object "Enable Summer/Winter". Firstly, the type of system must be 4 pipes On/Off. Next, configure all the standard datapoints required by the thermostat to operate correctly. Add the following groups:

group 1

"Enable - Summer/Winter": to perform the season change on the thermostat and disable the 3 speeds:

- "Speed V1 - Disable fan"
- "Speed V2 - Disable fan"
- "Speed V3 - Disable fan"
- "Status - Summer/winter"

group 2

To operate the radiating system with On/Off valve in winter:

- "Heating valve - valve"
- "Relay" (the relay of the device controlling the underfloor system valve)

Note: you can add to the group the object "Fan coil: Disable Local Operation" to disable the user interface of the fan coil during the winter season.

group 3

To operate the fan coil general On/Off valve in the summer:

- "Cooling valve - Valve"
- "Relay" (the relay of the device controlling the fan coil valve).

group 4

To control the fan coil speed V1 in summer:

- "Relay" (the relay of the device controlling the speed-1 of the fan coil)
- "Speed V1 - Fan Outputs".

group 5

To control the fan coil speed V2 in summer:

- "Relay" (the relay of the device controlling the speed-2 of the fan coil)
- "Speed V2 - Fan Outputs".

group 6

To control the fan coil speed V3 in summer:

- "Relay" (the relay of the device controlling the speed-3 of the fan coil)
- "Speed V3 - Fan Outputs".

In this configuration, when the thermostat is in Winter mode, *group 1* goes to "1" so the fan coil speeds are forcibly disabled to block their operation and the thermostat operates in On/Off only on the radiant heating valve as it is configured for 4-pipe On/Off systems with *group 2*; in Summer *group 1* goes to "0" and the 3 speeds can again be controlled from the bus; furthermore, the thermostat will operate with the general fan coil cooling valve of *group 3*. The *Groups 4, 5 and 6* are those of the 3 speeds and objects for the thermostat and they can be controlled from the thermostat when the first group goes to "0" by setting the thermostat in summer mode.

23. What objects are used to read the thermostat temperatures from the Well-Contact Suite software?

For thermostats 02972, objects 11 and 12 (weighted averages of the temperatures that can be associated) are used to read respectively the current temperatures of thermostats A/B, and not objects 0 and 10 of the device (which are the precise measurement data for the individual internal/external probes).

24. Is it possible to eliminate the adjustment range in Comfort mode, which can be expanded at the most to $\pm 5^{\circ}\text{C}$?

It is possible by setting the parameter "Guest Control Permitted" onto "No Limitation".

25. If a 0-100% proportional fan coil rather than a three-speed fan coil is controlled, will values 0-100% be sent to the fan coil?

Yes, if the "Type" fan parameter is selected on "Proportional (0-100%)".

26. How is the "Dewpoint" object used?

This object is used in systems with underfloor cooling and is associated with a KNX humidistat capable of detecting a level of humidity at which condensation may form on the floor. By activating the ETS group for this object, the thermostat will automatically go to "Off" mode, stopping air conditioning.

It is possible to set a time limit after which the thermostat will automatically go to "Off" if a message has not arrived from the KNX humidistat. This operation does not occur in heating mode.

27. How does the "Comfort" object work?

If "1" is sent to this object, the thermostat goes to "CMF" mode (unless the window has been opened in the event of window-contact control); if "0" is sent the thermostat goes to "Standby" mode

28. IS it possible for a thermostat to control a 0-100% proportional valve and an On/Off valve simultaneously?

No, it is not possible as setting the thermostat for proportional control disables On/Off control on the valve object. With two-zone thermostats (02952, 20430 and similar), it is possible to operate "Thermostat-A" in one mode and "Thermostat-B" in the other, but the guest would have to set both each time to activate both the proportional valve and the On/Off valve.

29. Can the thermostat be controlled from supervisors such as the KNX touch screen?

Yes, the thermostats are KNX standard so a KNX certified supervisor is capable of managing them.

30. How can operations performed by the guest on the thermostat (change of temperature and functions) be inhibited?

Using the objects "Temperature: Disable Local Operation" and "Fan coil: Disable Location Operation" you can block changes to fan coil temperature and speed. It is not possible to block the operating mode because the guest cannot decide this directly. For example, the guest can force the thermostat to Off only by opening the window or can set it to standby only by leaving the room (removing the card from the pocket reader).

FAQ

- 31. If a 1-bit thermostat comfort/stby object is associated with the "Guest in room" pocket object, when the Well-contact Suite software is started up, the thermostats that were in "Economy" or "Protected/Off" mode return automatically to STBY with higher setpoints.**

The "U" flag must be disabled in ETS for the thermostat object. If the "Guest in room" pocket object is associated with the 1 bit "Stby/Comfort" thermostat object, when a guest enters the room goes to "Comfort" mode. If within the same group the "R" read flag is enabled on the pocket object to allow the presence of a guest in the room to be interrogated by the WCS software, when it starts, the software performs interrogation polling on this group and the pocket responds with a "0" bit for the "Guest in room" object. If the flag "U" is active in that thermostat object, it takes the pocket response as an update for its operating mode and goes to Stby when perhaps it had been set to "Economy" mode or "Protected/Off" mode for an extended period of non-use of the room.

- 32. How can I update the thermostat setpoints and measured temperatures on a supervisor (e.g. Well-contact Suite)?**

To have the new setpoint status once a new setpoint has been set on the supervisor (regardless of the mode currently being used) you must go to the "SETPOINT" and "SENSOR PARAMETERS" parameters of the thermostat and set the values of "Send on Change" and "Cyclic Send Time" as preferred: if the system is very large you should perhaps set the send on difference to 0.3-0.5°C and not set the periodic send every x minutes so as not to overload the Bus with messages.

- 33. Is it possible to operate a thermostat in such a way that in the summer it controls a 0-100% proportional valve and in the winter a simple head in On/Off mode?**

Yes, this can be done by means of special programming of the thermostat and relay device that we will now look at in greater detail, provided the On/Off head is not controlled by the relay on the thermostat (which does not have the logic function described below) but by a relay of other devices such as an 01523.1 or a 14457, etc.. YOU have to set the thermostat VALVE parameter to "4 pipe proportional with proportional/integral control" mode. This way you have 2 separate "1 byte proportional valve" objects for each season and will use only the one for the summer (whereas for the winter you will not use the corresponding 1 byte object). For winter mode, set the thermostat FAN parameters as "Maximum speed 1", in other words use the corresponding object of "Speed-1" given that when the winter valve is activated by a thermostat heating request, this object will certainly also be activated. Given that the thermostat's season change object goes to "1" in winter status and "0" if you set the summer season, you can then work with a relay, for example a 01523.1 on which you can activate the parameter "1 OBJECT LOGIC function" (setting it in "AND" mode). You can then create a first group with the "On/Off control" of the relay together with the "Speed 1" object of the thermostat (this serves to control the heating head) and then another group with "object no. 18 summer/winter status" of the associated thermostat together with the object "Logic 1" of relay 01523.1. In functional terms, in winter the "logic 1 of 01523.1" group is activated, so when the other group (i.e. that of the thermostat object + relay On/Off control) also goes to 1, the relay 01523.1 will switch towards the head. In summer the first of the two groups will be constantly at "0", so the On/Off messages reaching the 2nd group from the thermostat object will not cause the relay to move.

- 34. Is it possible to control a fan coil by using any free relays of the various devices without using the 4 I/O device (art. 01522.1) or the relay actuator (art. 01523.1)?**

Yes, it is possible; however, to prevent the user via supervision from mistakenly activating a speed relay while a similar relay is also activated by the thermostat, it is necessary in the ETS project to avoid pairing the force-speed objects nos. 45 - 48.

- 35. In a hotel, the thermostats set to OFF/Economy mode suddenly all go into STBY mode; why is that?**

The mode change has been generated by the Well-contact Suite software reopening which on starting up queries all the room pockets to update its supervision on the presence or absence of guests in the rooms; the pockets respond with a bit=0 on the presence, but this is the same group that is also linked to the 1 bit object of the CMF/STBY control of the thermostats and bit=0 on that group entails an interpretation of the thermostat of the type "guest not in room, go onto STBY". The problem can be solved by disabling the Update flag "U" on the 1 bit object of "comfort/stby" of the thermostat that is active by default; in this way, when the Well-contact Suite software queries the pockets, they respond with a bit=0 on the group but since that flag is OFF, the thermostat will keep its mode without going onto STBY.

- 36. If the thermostat is operating in Neutral Zone mode and the guest changes the current setpoint by adjusting the thermostat, what happens? Are the setpoints previously set by ETS or by Well-contact Suite also changed?**

No, nothing in particular happens. Acting on the thermostat changes only the Current Setpoint and not the single mode/season setpoints, the thermostat functions according to the set setpoint and the room temperature so it will activate the heating, cooling or remain in the neutral zone depending on the heating and air-conditioning setpoints of the current mode.

- 37. You cannot change the thermostat mode from the Well-Contact Suite software (neither from supervision nor from the Master-thermostat); What can be done?**

To send mode messages to the thermostats, the Well-contact Suite software uses the communication objects No. 17 for thermostat-A and No. 68 for thermostat-B.

- 38. Is it possible to control a fan coil via a relay belonging to different devices and not to a 4-output module?**

Yes, it is possible. The thermostat automatically performs an interlocking function between the relays of the various speeds so it deactivates the relay in use before activating that of the new speed to switch on; to prevent the guest from accidentally activating the 2 relays at the same time causing failure of the Fan coil, in the ETS project it is necessary not to pair the speed forcing objects to avoid the guest forcing one speed when another one is already in use (it is not possible to interlock relays of different devices).

- 39. Can the various Setpoint communication objects be added to the same ETS group?**

No, each thermostat communication object must be added to its own dedicated group.

FAQ

40. Is it possible not to show the icon for swapping between Thermostat A and Thermostat B on the display?

Yes. So as not to display the icon on the bottom left you need to Disable the "Enable User Interface" item of the "Thermostat B" parameter.

41. Using the Setpoint Shift object and resetting this setting when you switch the thermostat to ECONOMY or OFF/PROTECTED mode.

If with a supervisor device (touch screen, web server, etc.) you change the current setpoint of a thermostat, in which the Reset Setpoint Shift in Economy Mode parameter is set = yes, via the SETPOINT SHIFT object and, at a later time, you bring it into ECONOMY mode, when the thermostat is put back in STBY or CMF mode the value previously set by the supervisor will not be maintained (conversely, if you write the value directly on the SUMM/WINT COMFORT SETPOINT object or on SUMM/WINT STBY SETPOINT there will not be a reset when the mode changes).

42. Is it possible to have a Boost function to supplement the heating? And will this make it possible to determine the 3 speeds of the fan coil?

The section of the parameters referred to as "2nd HEATING/COOLING STAGE" illustrates how the thermostat is able to activate an additional system, which will only be on/off, or a control of a proportional valve 0-100% by means of the objects Nos. 36 and 37 which will appear by activating this Boost function. The thermostat is not able to manage the Boost function by determining the speeds with 3 relays so either it will be on/off or proportional 0-100% (whose possible value is either 0% for power-off or 100% for fully open).

43. Is it possible to have the thermostat 02972 send a 1 bit ON message when the thermostat turns off all the speeds?

Yes, and this function is required by some temperature control gateways to manage the Off of the fan coils when the thermostat has switched off the speeds: the communication object is called "OFF - Fan outputs" and the thermostat automatically sends a bit=1 when the fans are turned off and bit=0 when they are turned back on.

44. If the speeds of the fan coils are forced to OFF, will the thermostat reset to AUTO when it changes mode or simply when Well-contact Suite queries the room pocket to know whether the guest is present in the room?

When Well-contact Suite queries a pocket it responds with a bit equal to 0/1 on the same control group as the CMF/STBY mode of the thermostat causing the mode control to be sent again. The thermostat is designed to reset forcing when it receives a mode control so it eliminates the forcing-OFF of the fans; to work around this problem, in the ETS project you can remove the "U" flag of the object of CMF/STBY and reprogram the thermostat so that the response sent from the pocket to the Well-contact Suite software is ignored.

45. How does the "Neutral Zone" mode function for a 4-pipe system?

If the "Enable Summer/Winter" object of thermostat A and/or thermostat B is not paired with any ETS group, the thermostat in question will function in Neutral Zone mode; in this mode it will be the thermostat that activates the Air-Conditioning or Heating circuit depending on the room temperature, the Summer and Winter setpoints for the currently selected mode (CMF/STBY/etc.) with a room temperature range, called Neutral Zone, within which neither circuit will be activated. If the end user increases or decreases the setpoint by using the thermostat it will not change the two summer/winter setpoints but will change a setpoint that is halfway between those two values which is the central reference of the neutral zone; raising or lowering this value will also automatically increase or decrease the two setpoints related to summer/winter for the active mode (CMF/STBY) so as to keep the neutral zone unchanged. The thermostat activates the heating or air-conditioning according to the two summer/winter setpoints so, if the room temperature is not in the neutral zone, the thermostat will take as reference the setpoint that is closest to the current temperature (summer/winter) resulting in the activation of the heating or air-conditioning circuit.



02972IEN 04 2410



VIMAR

Viale Vicenza 14
36063 Marostica VI - Italy
www.vimar.com